

VOLVO B9R SIDERAL



K

P

1 2

3 4

5 6

7 8

9 10

11 12

13 14

15 16

17 18

19 20

21 22

23 24

25 26

27 28

29 30

31 32

33 34

35 36

37 38

39 40

41 42

43 44

45 46

47 48

49 50

51 52

53 54

55 56 57

WEJŚCIE



WEJŚCIE

Legenda

1

MIEJSCE
SIDZĄCE

K

KIEROWCA

P

PILOT